



"Infection Prevention from A to UV"

Providing you with UV solutions for your disinfection needs

ClorDiSys UV Sensor

Part# 116-101

Description:

Our UV Sensor allows for the continuous monitoring of UV-C intensity during a disinfection cycle. The UV Sensor reads UV-C intensity and provides a cumulative UV-C dosage that is being exhibited at that distance. The room number can also be entered for documentation purposes. These values, along with the corresponding time and date stamp, are saved via USB drive so that the data file can be used for infection control and housekeeping logs. The Sensor Box can be located outside of the room being disinfected, while the Sensor itself is located at a specific distance or location to provide the UV-C dosage being delivered to that position.



Dimensions:

Sensor Box
13.5"W x 12"H x 6"D
(34cm x 30cm x 15cm)

Sensor
6" W x 9" H x 9"D
(15cm x 23cm x 23cm)



P.O. Box 549, Lebanon, NJ 08833-0549 Tel: (908) 236-4100 Fax: (908) 236-2222

www.cleanhospital.com

Rev 8-2015